


Parts Breakdown

Model BC-CN-0003 41454



Parts Breakdown

Model BC-CN-0003 41454

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AU796	Control PCB for 41454	1	AU812	Main Body Assembly for 41454	17	AU828	Rear Partition for 41454	33
AU797	Membrane Switch for 41454	2	AU813	Muffler for 41454	18	AU829	Chassis Mounting Block for 41454	34
AU798	Chassis Front Control Panel for 41454	3	AU814	Exhaust Tube for 41454	19	AU830	Dust Filter Rail for 41454	35
AU799	Compactor for 41454	4	AU815	Filter for 41454	20	AU831	Chassis Side Panel Mounting Block for 41454	36
AU800	Electrical Box for 41454	5	AU816	Pallet Board for 41454	21	AU832	Chassis Mounting Top Block for 41454	37
AU801	Condenser for 41454	6	AU817	Pallet Plate 1 for 41454	22	AU833	Chassis Rear Mounting Block for 41454	38
AU802	PCB Spacer for 41454	7	AU818	Evaporator for 41454	23	AU834	Upper Door Axle Plate for 41454	39
AU803	Mainboard for 41454	8	AU819	Three-Way Tube for 41454	24	AU835	Lower Door Axle Plate for 41454	40
AU804	Dust Filter for 41454	9	AU820	Fan for 41454	25	AU836	Power Cord Buckle for 41454	41
AU805	Power Supply PCB for 41454	10	AU821	Back Duct Board for 41454	26	AU837	Supporting Foot for 41454	42
AU806	Adjusting Foot for 41454	11	AU822	Door Seal (Including Packaging) for 41454	27	AU838	Compressor Connection Tube for 41454	43
AU807	Chassis Side Panel for 41454	12	AU823	Door Panel Foaming for 41454	28	AU839	Capillary Tube for 41454	44
AU808	Chassis Rear Panel for 41454	13	AU824	Defrost Connection Tube for 41454	29	AU840	Three-Way Connecting Tube for 41454	45
AU809	Windbreak Panel for 41454	14	AU825	Process Tube for 41454	30	AU841	Silver Mesh Cover for 41454	46
AU810	Chassis Welding Fittings for 41454	15	AU826	Solenoid Valve Connection Tube for 41454	31	AU842	Temperature Sensitive Probe for 41454	47
AU811	FDF Solenoid Valve for 41454	16	AU827	Three-Way Connecting Tube for 41454	32			