


Parts Breakdown

Model FW-CN-0004-H 48173



Parts Breakdown

Model FW-CN-0004-H 48173

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AU421	Right Support on Right Side for 48173	1	AS348	Pole for 48173	20	AU445	Heat Insulation Pad (Bottom) for 48173	39
AU422	Right Pillar on Right Side for 48173	2	AU432	Pan for 48173	21	AU446	Channels-B (Bottom) for 48173	40
AU423	Right Pillar Connector for 48173	3	AU433	Shelf for 48173	22	AU447	Channels Fixed Plate (Bottom) for 48173	41
AU426	Computer Version of Fixed Plate (Outside) for 48173	4	AU463	Top Cover Plate for 48173	23	AS338	Temperature Sensor for 48173	42
AU424	Left Pillar on Right Side for 48173	5	AS312	Fan Motor for 48173	24	AS339	Probe Fixter for 48173	43
AU460	Left Support on Right Side for 48173	6	AU435	Air Duct Assembly for 48173	25	70863	Thermostat T1M/33 for 48173	44
AR485	Switch (Higher Amp) for 48173	7	AU464	Upper Connection for 48173	26, 46	AU465	Pillar (Middle) for 48173	45
AS324	Transformer for 48173	8	AU437	Insulation for 48173	27	AU448	Left Pillar Connector for 48173	47
AS330	Sliding Rail for 48173	9	AU438	Aluminum Foil Heater for 48173	28	AU449	Left Plate for 48173	48
AS318	Display Fixed Plate Assembly Right (Top) for 48173	10	AU441	Channels-A (Top) for 48173	29	AD870	Fixed Plate for 48173	49
AU427	Loudspeaker for 48173	11	AS341	Display Board (W2) for 48173	30	AD869	Equipotential Grounding Block for 48173	50
AU428	Right Plate for 48173	12	AS332	Display Board (W1) for 48173	31	AS303	Foot Pad for 48173	51
AU429	Tags (Main Control Board) for 48173	13	AS343	Insulating Column for 48173	32	AS301	Rubber Feet for 48173	52
AS326	Computer Version of Fixed Plate for 48173	14	AS344	Sticker Fixing Plate for 48173	33	61245	Wire Clamp Cover for 48173	53
AU430	Main Control Board for 48173	15	AU439	Tags (Window Display) for 48173	34	61246	Wire Clip Holder for 48173	54
AS342	Insulating Washer for 48173	16	AU440	Heat Insulation Pad (Top) for 48173	35	AK995	Power Line for 48173	55
AU431	Insulating Column(5) for 48173	17	AU442	Channels-B (Top) for 48173	36	67691	Power Cord for 48173	56
AU461	Plate (Bottom) for 48173	18	AU443	Channels Fixed Plate (Top) for 48173	37			
AU462	Plate (Top) for 48173	19	AU444	Channels-A (Bottom) for 48173	38			