


Parts Breakdown

Model DW-CN-0902 21570



Parts Breakdown

Model DW-CN-0902 21570

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
66044	Clip with Screw for 21570	1	24770	Front / Back Door Handle for 21570	12, 25	24768	White Decorating Plate for 21570	23
24746	Plug and Power Cord for 21570	2	24758	Front Glass 400x417mm for 21570	13	24769	Back Glass 394x417mm for 21570	24
41081	Thermostat with Knob for 21570	3	24759	315 Shelf for 21570	14	24771	Cover of Heater for 21570	26
24749	Indicator Light for 21570	4	24760	350 Shelf for 21570	15	24772	GN Pan for 21570	27
24750	Switch for 21570	5	24761	360 Shelf for 21570	16	26019	Fluorescent Tube only 8 Watt for 21570	28
24751	Temperature Display for 21570	6	24762	Vertical Support for 21570	17	28728	Right or Left Side Glass for 21570	29, 30
24752	Bracket of Heater for 21570	7	28735	Left Bracket for Shelves for 21570	18	66059	40W Light Holder for 21570	32
24753	Heater / Heating Element for 21570	8	24764	40W Light for 21570	19	24763	Right Bracket for Shelves for 21570	33
24754	Base for 21570	9	24765	Middle-Level Assembly for 21570	20	28736	Fluorescent Tube Holder for 21570	34
24755	Plastic Foot for 21570	10	24766	110V Ballast for 21570	21	28737	Right Fluorescent Tube Cover for 21570	35
24756	Door Guide for 21570	11	24767	Top Cover for 21570	22	28738	Left Fluorescent Tube Cover for 21570	36