


Parts Breakdown

Model DW-CN-0686 21749



Parts Breakdown

Model DW-CN-0686 21749

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
66044	Clip with Screw for 21749	1	24770	Front / Back Door Handle for 21749	12, 25	24795	White Decorating Plate for 21749	23
24746	Plug and Power Cord for 21749	2	24785	Front Glass 440x300mm for 21749	13	24796	Back Glass 436x300mm for 21749	24
41081	Thermostat with Knob for 21749	3	24786	315 Shelf for 21749	14	24798	Cover of Heater for 21749	26
24749	Indicator Light for 21749	4	24787	350 Shelf for 21749	15	24772	GN Pan for 21749	27
24750	Switch for 21749	5	24788	360 Shelf for 21749	16	26019	Fluorescent Tube only 8 Watt for 21749	28
24751	Temperature Display for 21749	6	24789	Vertical Support for 21749	17	21399	Right or Left Side Glass for 21749	29, 30
24779	Bracket of Heater for 21749	7	66063	Left Bracket for Shelf for 21749	18	66059	40W Light Holder for 21749	32
24780	Heater for 21749	8	24764	40W Light for 21749	19	66064	Right Bracket for Shelf for 21749	33
24781	Base for 21749	9	24792	Middle-Level Assembly for 21749	20	66065	Light Tube Holder for 21749	34
24755	Plastic Foot for 21749	10	24766	110V Ballast for 21749	21	28737	Right Fluorescent Tube Cover for 21749	35
24783	Door Guide for 21749	11	24794	Top Cover for 21749	22	28738	Left Fluorescent Tube Cover for 21749	36