


# Parts Breakdown

Model PE-CN-1800-S 24210



# Parts Breakdown

---

## Model PE-CN-1800-S 24210

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
78408	Top Cover for 24210	1	78415	Side Plates for 24210	9	78423	Switch (Yellow-Green) for 24210	17
78409	Inside Spun Blanket Fixed Plate for 24210	2	78416	Bottom Cover for 24210	10	78424	Brick for 24210	18
78410	Chimney for 24210	3	78417	Feet for 24210	11	78425	Door for 24210	19
78411	Back Plate for 24210	4	78418	Thermometer for 24210	12	78426	Top Protecting Plates for Box for 24210	20
78412	Thermal Cut Out for 24210	5	78419	Thermostat for 24210	13	78427	Element for 24210	21
AF725	Lamp 120V for 24210	6	78420	Timer for 24210	14	78428	Bottom Protecting Plates for Box for 24210	22
78413	Plug and Lead for 24210	7	78421	Dial for 24210	15	78429	Inside Plate for 24210	23
78414	Insulation Plate for 24210	8	78422	Switch (Yellow) for 24210	16			