


Parts Breakdown

Model **DI-CN-0010** 31840



Parts Breakdown

Model DI-CN-0010 31840

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
73902	Tank Cover for 31840	1-A	73918	Cover of Overheat Protector for 31840	15	73934	Moving Pin for 31840	31
73903	Knob of Tank Lid for 31840	1-B	73919	Button of Overheat Protector for 31840	16	73935	Faucet Spring for 31840	32
73904	Paddle for 31840	2	73920	Button Stop of Protector for 31840	17	73936	Cleaner Shaft for 31840	33
73905	Lid of Stirring Rod for 31840	3-A	73921	Tank Hinge for 31840	18	73937	Tap Handle for 31840	34
73906	Stirring Rod for 31840	3-B	73922	Upper Exterior for 31840	19	73938	Screw of Faucet for 31840	35
73907	PC Tank for 31840	4	73923	Lower Exterior for 31840	20	73939	Pin Spring for 31840	36
73908	Gasket of PC Tank for 31840	5	73924	Power Switch for 31840	21	73940	Pin for 31840	37
73909	Stainless Steel Boiler (Upper Part) for 31840	6	73925	Thermostat for 31840	22	73941	Lid of Water Bin for 31840	38
73910	Gasket for 31840	7	73926	Foot for 31840	23	73942	Water Bin for 31840	39
73911	Overheat Protector for 31840	8	73927	Ventilation Grill for 31840	24	73943	Drainage Plug for 31840	40
73912	Heater Element for 31840	9	73928	Washer of Faucet (Interior) for 31840	25	73944	Lid of Water Tray for 31840	41
73913	Boiler Gasket for 31840	10	73929	Nut of Faucet (Interior) for 31840	26	73945	Floater for 31840	42
73914	Stainless Steel Boiler (Lower Part) for 31840	11	76479	Gasket of Faucet for 31840	27	73946	Water Tray for 31840	43
73915	Supporter for 31840	12	73931	Nut of Faucet (Exterior) for 31840	28	73947	Supporter of Fan for 31840	44
73916	Motor for 31840	13	73932	Gasket of Faucet Screw for 31840	29	39257	Fan for 31840	45
76466	Back Cover for 31840	14	76482	Gasket Inside the Faucet for 31840	30			