


Parts Breakdown

Model **DI-CN-0005** 39482



Parts Breakdown

Model DI-CN-0005 39482

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
73902	Tank Cover for 39482	1-A	73918	Cover of Overheat Protector for 39482	15	73934	Moving Pin for 39482	31
73903	Knob of Tank Lid for 39482	1-B	73919	Button of Overheat Protector for 39482	16	73935	Faucet Spring for 39482	32
76453	Paddle for 39482	2	73920	Button Stop of Protector for 39482	17	73936	Cleaner Shaft for 39482	33
73905	Lid of Stirring Rod for 39482	3-A	73921	Tank Hinge for 39482	18	73937	Tap Handle for 39482	34
76455	Stirring Rod for 39482	3-B	73922	Upper Exterior for 39482	19	73938	Screw of Faucet for 39482	35
76456	PC Tank for 39482	4	73923	Lower Exterior for 39482	20	73939	Pin Spring for 39482	36
73908	Gasket of PC Tank for 39482	5	73924	Power Switch for 39482	21	73940	Pin for 39482	37
76458	Stainless Steel Boiler (Upper Part) for 39482	6	73925	Thermostat for 39482	22	73941	Lid of Water Bin for 39482	38
73910	Gasket for 39482	7	73926	Foot for 39482	23	73942	Water Bin for 39482	39
73911	Overheat Protector for 39482	8	73927	Ventilation Grill for 39482	24	73943	Drainage Plug for 39482	40
73912	Heater Element for 39482	9	73928	Washer of Faucet (Interior) for 39482	25	73944	Lid of Water Tray for 39482	41
73913	Boiler Gasket for 39482	10	73929	Nut of Faucet (Interior) for 39482	26	73945	Floater for 39482	42
73914	Stainless Steel Boiler (Lower Part) for 39482	11	76479	Gasket of Faucet for 39482	27	73946	Water Tray for 39482	43
73915	Supporter for 39482	12	73931	Nut of Faucet (Exterior) for 39482	28	73947	Supporter of Fan for 39482	44
73916	Motor for 39482	13	73932	Gasket of Faucet Screw for 39482	29	39257	Fan for 39482	45
76466	Back Cover for 39482	14	76482	Gasket Inside the Faucet for 39482	30			