



Parts Breakdown

Model JE-ES-0015-S 39518



Parts Breakdown


Model JE-ES-0015-S 39518




Parts Breakdown

Model JE-ES-0015-S 39518

STAINLESS STEEL SELF TAP OPTION



AUTOMATIC SHOWER OPTION



Parts Breakdown

Model JE-ES-0015-S 39518

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|--|----------|----------|---|----------|----------|--|----------|
| 72499 | Stainless Steel Basket for 39518 | 00020 | 72535 | Plastic Lid M6 for 39518 | 00286 | 72580 | Rustless Screw M2.9x10 Inox for 39518 | 00541 |
| 72500 | Screw H M4x10 Zinc for 39518 | 00035 | 40592 | Female Thumbscrew M8 for 39518 | 00287 | 72582 | Rustless Screw M5x10 Inox for 39518 | 00555 |
| 72501 | Rustless Washer DIN-9021 D06 for 39518 | 00040 | 72537 | Male Thumbscrew M6 for 39518 | 00289 | 72583 | Reducer Shaft for 39518 | 00562 |
| 72502 | Screw H M8x30 Zinc for 39518 | 00048 | 72538 | Feeder Tube Support Clamp for 39518 | 00311 | 40589 | Male Thumbscrew M8 for 39518 | 00590 |
| 72503 | Turning Feeder Plate for 39518 | 00055 | 72539 | Feeder Tube Support MM for 39518 | 00313 | 72585 | Peel Bucket for 39518 | 00594 |
| 72504 | Cotter H 8x7x15 for 39518 | 00065 | 72540 | Feeder Tube Support MX for 39518 | 00314 | 72586 | Screw H M10x35 Zinc for 39518 | 00611 |
| 72505 | Cotter H 8x7x50 for 39518 | 00066 | AK891 | E-Tron Basic Support for 39518 | 00320 | AK892 | E-Tron Joint for 39518 | 00620 |
| 72506 | Rustless Cotter Inox 8x7x70 for 39518 | 00067 | 72541 | Tray 150x120 for 39518 | 00322 | 64837 | DC Shower Diffuser for 39518 | 00660 |
| 72507 | Screw H M8x25 Zinc for 39518 | 00072 | 72542 | Sump Base for 39518 | 00325 | 64838 | DC Shower Diffuser Cap for 39518 | 00661 |
| 72508 | Bearing 6007 for 39518 | 00083 | 72543 | Squeezer Double Drum for 39518 | 00333 | 64839 | DC O-Ring for 39518 | 00662 |
| 72509 | Rustless Screw M4x10 Inox for 39518 | 00086 | 72545 | Sump Grid for 39518 | 00336 | 72612 | Feeder Tube Protection for 39518 | 00667 |
| 72510 | Blade Rod-Positioner for 39518 | 00089 | 72547 | Cover Screen Support Cap for 39518 | 00348 | 64840 | Lower Gear for 39518 | 00669 |
| 40585 | Knife Piece for 39518 | 00093 | 72548 | Cover Screen Support for 39518 | 00361 | 40587 | Rustless Juice Filter for 39518 | 00675 |
| 71506 | Squeezer Male for 39518 | 00095 | 72549 | Feeder Support for 39518 | 00363 | 64841 | Plugging Cap Ø19mm for 39518 | 00692 |
| 40593 | Ejector for 39518 | 00098 | 72550 | Juice Tray for 39518 | 00372 | AK893 | Tap Handle for 39518 | 00707 |
| 72514 | Ventilation Grid for 39518 | 00108 | 72551 | Juice Tray (Self) for 39518 | 00373 | 72597 | Lower Seal Protection for 39518 | 00717 |
| 72515 | Lower Rustless Shaft for 39518 | 00111 | 72552 | Feeder Tube Protection for 39518 | 00395 | 64842 | Reducer for 39518 | 00723 |
| 72516 | Upper Rustless Shaft for 39518 | 00113 | 72553 | Feeder Tube for 39518 | 00396 | 64843 | Rustless Screw M2.9x16 Inox for 39518 | 00752 |
| 72518 | Upper Gear for 39518 | 00115 | 72554 | Back Cover MM for 39518 | 00397 | 44090 | Rustless Screw DIN-85 M4x14 Inox for 39518 | 00753 |
| 72519 | Lower Gear for 39518 | 00117 | 39696 | Cover Screen for 39518 | 00400 | 72589 | Screw H M6x16 for 39518 | 00768 |
| 72520 | C Clip Din 471 E-34 for 39518 | 00168 | 72556 | Back Cover MX for 39518 | 00404 | 64845 | Rustless Screw M4x16 Inox for 39518 | 00769 |
| 72521 | Washer H D35-D09x3 Zinc for 39518 | 00171 | 72557 | Plugging Cap Ø5x12mm for 39518 | 00408 | 64846 | DC Adapter Female 6-1/4" for 39518 | 00770 |
| 72522 | Rustless Washer Din-125 D08 Inox for 39518 | 00174 | 72560 | Lower Seal Protection for 39518 | 00426 | 64847 | DC Adapter Male 6-1/4" for 39518 | 00772 |
| 72523 | Stainless Cotter 8x8x170 Inox for 39518 | 00176 | 72561 | Upper Seal Protection for 39518 | 00427 | 64849 | DC Elbow 6mm for 39518 | 00776 |
| 40590 | Male Thumbscrew M8 for 39518 | 00178 | 72563 | Rustless Screw M6x20 Inox for 39518 | 00431 | 64851 | DC Hose 6mm for 39518 | 00781 |
| 64906 | Nut H Zinc M8 for 39518 | 00188 | 72564 | Rustless Screw M6x12 Inox for 39518 | 00432 | 64853 | DC E-Valve Shower Support for 39518 | 00785 |
| 72526 | Rustless Wingnut M4 Inox for 39518 | 00189 | 72565 | Rustless Washer Din-6798 D06 Inox for 39518 | 00436 | 64855 | DC Valve 1/4" for 39518 | 00789 |
| 40586 | Positioner Orange Color for 39518 | 00194 | 64835 | Sump Bearing Lid for 39518 | 00442 | AK894 | Plugging Cap for 39518 | 00821 |
| 72528 | Positioner Guide for 39518 | 00195 | 72692 | Traction Disc Feeder for 39518 | 00480 | 64856 | Pin Detect D8 for 39518 | 00836 |
| 72529 | Rubber Seal 35x50x07 for 39518 | 00198 | 72568 | Head Feeder for 39518 | 00485 | 64857 | Tap Plunger for 39518 | 00847 |
| 72530 | Positioner Lid for 39518 | 00200 | 72569 | Rustless Feeder Shaft for 39518 | 00487 | 64858 | Plunger O-Ring Ø2 for 39518 | 00848 |
| 64834 | Plugging Cap Ø16mm Black for 39518 | 00212 | 72570 | Feeder Traction Disc Supply for 39518 | 00488 | 64859 | Plunger O-Ring Ø4 for 39518 | 00849 |
| 40594 | Rustless Juice Filter for 39518 | 00217 | 72693 | C Clip DIN-471 E16 for 39518 | 00489 | 64860 | Tap Handle for 39518 | 00850 |
| 72532 | Luggage-Rack 150x120 for 39518 | 00219 | 72572 | Washer H D28-D06x2 Zinc for 39518 | 00502 | 64861 | Tap Spring for 39518 | 00851 |
| 72533 | Gear Feeder 3 Horiz for 39518 | 00226 | 72573 | Rustless Screw M6x10 Inox for 39518 | 00503 | 64862 | Tap Cap for 39518 | 00852 |
| 72534 | Plastic Lid M4 for 39518 | 00285 | 72574 | Gear Feeder for 39518 | 00516 | 64863 | Magnet 10-10 for 39518 | 00854 |

Parts Breakdown

Model JE-ES-0015-S 39518

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|--|----------|----------|---------------------------------------|----------|----------|-------------------------------------|----------|
| 64864 | Tap Body for 39518 | 00855 | 64871 | Tube DET Nut for 39518 | 00863 | 64876 | Self Service Inox Tap Kit for 39518 | 70008 |
| 64865 | Rustless Washer Din-125 D05 Inox for 39518 | 00856 | 64872 | Nut H CRO M12x100 for 39518 | 00864 | 72615 | Feeder Tube Kit MM for 39518 | 70009 |
| 64866 | Rustless Screw for 39518 | 00857 | AK895 | Frontal Sheet for 39518 | 00869 | 72616 | Feeder Tube Kit MX for 39518 | 70013 |
| 64867 | Tap Capsule for 39518 | 00858 | 64873 | Back Cover for 39518 | 00878 | 72617 | Sump Kit for 39518 | 70026 |
| 64868 | Magnet 10-05 for 39518 | 00859 | 64874 | Back Cover for 39518 | 00880 | 64877 | Shower Sump Kit for 39518 | 70027 |
| 64869 | Tap Support for 39518 | 00860 | 64875 | Rustless Screw M2.9x13 Inox for 39518 | 00882 | | | |
| 64950 | Tube DET-180 Stainless Steel for 39518 | 00862 | 72614 | Feeder Support Kit for 39518 | 70004 | | | |