


Parts Breakdown

Model Santos 10 39687





Parts Breakdown

Model Santos 10 39687

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
39729	Complete Lever for 39687	10100	73120	Friction Plate for 39687	10504	AM922	Complete Motor 110V 60Hz for 39687	10730B
40683	Black Lever for 39687	10101	73121	Intermediate Flange Only for 39687	10505	AC370	Complete Rotor with Shaft for 39687	10731
40421	Lever Axle (Pin) D8x34 for 39687	10102	73122	Screw H4x12 for 39687	10506	AM923	Stator Only 110V 60HZ for 39687	10732B
40684	Complete Cup with Screw and Washer for 39687	10103	40699	Complete Friction Clutch for 39687	10600	AC371	Lower Flange for 39687	10741
40685	Cup Locking Screw for 39687	10104	40700	Friction Clutch & Disc (Welded) for 39687	10601	AC372	Ondulated Washer for 39687	10742
40686	Stainless Steel Cup Only for 39687	10105	40701	Screw HC M5x10 Stainless Steel for 39687	10605	73141	Stainless Steel Housing for 39687	10800
40687	Stainless Steel Washer for 39687	10106	40529	Stainless Steel Driving Pin for 39687	10606	73143	Painted Base Only (Grey) for 39687	10901
73114	Stainless Steel Cover Only for 39687	10107	40702	Fiber Pushing Pin for 39687	10607	40706	Plastic Drip Tray for 39687	10903
73115	Stainless Steel Spring for 39687	10108	40703	Steel Ball D 6 for 39687	10608	73144	Bottom Plate for 39687	10904
73116	Stainless Steel Spring Cap for 39687	10109	40704	Brake Stainless Steel Spring for 39687	10609	40707	Switch for 39687	10905
73117	Lever Washer for 39687	10110	40705	Complete Drive Plate for 39687	10610	AM924	On-Off Plate (110V UL) for 39687	10906B
40688	Perforated Strainer (Stainless Steel) for 39687	10200	AC367	Screw HC M6x8 for 39687	10613	73147	Washer 4x10 for 39687	10908
40689	Complete Stainless Steel Bowl with Nut for 39687	10300	73125	Complete Upper Flange for 39687	10701	73148	Screw H 4x16 ZN for 39687	10909
73118	Stainless Steel Bowl for 39687	10301	73126	Upper Flange for 39687	10702	73149	Screw H 4x10 for 39687	10910
40690	Nylon Nut for 39687	10304	73127	Bearing 6201 for 39687	10703	44063	Power Cord with USA Plug for 39687	10912B
40691	Gasket D12x22x5 for 39687	10305	73128	Bearing Washer for 39687	10704	73151	Screw 4.8x16 ZN for 39687	10913
40692	Polyethylene Washer for 39687	10306	73129	Screw H 4x10 ZN for 39687	10705	73153	Screw 4x10 for 39687	10917
40693	Painted Aluminum Top (Bowl) with 4 Nuts for 39687	10400	73132	Bearing 6201 for 39687	10712	73156	Screw H M5x12 ZN for 39687	10920
40694	Painted Aluminum Top Only (Bowl) for 39687	10401	73134	Screw H 4x10 ZN for 39687	10714	AM925	Ground Symbol for 39687	10922
40695	Bowl Locking Nut for 39687	10402	73135	Assembling Threaded Rod M5 for 39687	10721	AM926	Washer AZ 8 for 39687	10924
40696	Complete Intermediate Flange for 39687	10500	73136	Nut H M5 ZN for 39687	10722	AM927	Nut H M8 Zn for 39687	10925
70795	Condenser for 39687	10501	73137	Split Washer D 5 for 39687	10723	AM928	Foot (for NSF 110V) for 39687	10933
40697	Bronze Bearing for 39687	10502	73138	Washer AZ 5 for 39687	10724	AM929	Cap (for 110V) for 39687	10934
40698	Gasket 12x22x5 for 39687	10503	73139	Washer 6x18 for 39687	10725	AM930	Complete Painted Base NSF 110V for 39687	10950B