


# Parts Breakdown

Model DW-CN-0137 40001



# Parts Breakdown

## Model DW-CN-0137 40001

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
70819	Rubber Feet Left for 40001	1	70888	Magnet Strip for 40001	16	60218	Indicator Light for 40001	33
70820	Rubber Feet Right for 40001	2	70837	Side Glass for 40001	17	70855	Lamp Holder for 40001	34
70874	Bottom Board for 40001	3	70890	Component of Front Panel for 40001	18	70856	Lamp Bracket for 40001	35
70875	Bottom Frame for 40001	4	70891	Magnet for 40001	19	70857	Electronic Ballast for 40001	36
70876	Tray for Heater for 40001	5	70892	Ceiling Board for 40001	20	70858	Fluorescent Lamp for 40001	37
70701	Heater Element for 40001	6	70893	Control Panel for 40001	21	70861	Back Pillar for 40001	38
67333	Heater Brace for 40001	7	70894	Cover Board for 40001	22	70863	Thermostat T1M/33 for 40001	39
70879	Component of Front Panel for 40001	8	70844	Transparent Lamp Cover for 40001	23	70862	Thermostat T1/33 for 40001	40
70932	Ventilated Board for 40001	9	70845	Fixed Plate for Lamp Cover for 40001	24	60741	Power Line for 40001	41
70882	Back Panel for 40001	10	70686	Temperature Display for 40001	25	70917	Decorative Strip for 40001	42
70883	Door Hinge for 40001	11	70898	Component of Front Panel for 40001	26	70969	Curved Glass for 40001	43
70935	Door Glass for 40001	12	70899	Transparent Plate for 40001	27	70869	Shelf Clamp for 40001	44
70675	Sheath of Door Knob for 40001	13	71640	Temperature Thermostat for 40001	28	70920	Shelf for 40001	45
70833	Front Pillar for 40001	14	70852	Advertisement Board for 40001	31	70916	Plug Clamp for 40001	46
70938	Door Frame for 40001	15	70688	Switch for 40001	32			