


Parts Breakdown

Model Santos 02 40619



Parts Breakdown

Model Santos 02 40619

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|---|----------|----------|--|----------|----------|---|----------|
| 73603 | Aluminum Lever for 40619 | 02122 | 73632 | Complete Grater Housing for 40619 | 02190 | 73657 | Motor Protector Spring for 40619 | 02338 |
| 73604 | Grater Housing for 40619 | 02124 | 73633 | Complete Grating Disc 3mm with Screw for 40619 | 02200 | 73658 | Ondulated Washer 6202 for 40619 | 02340 |
| 73605 | Grooved Pin 5x22 for 40619 | 02125 | 40950 | Grating Disc Complete Assembly - 2mm Holes for 40619 | 02201AD | 73659 | Flange for 40619 | 02341 |
| 73606 | Locking Key for 40619 | 02126 | 40951 | Grating Disc Complete Assembly - 3mm Holes for 40619 | 02201BD | 73660 | Screw FS M5x16 Stainless Steel for 40619 | 02342 |
| 73607 | Drawer Sustainer for 40619 | 02127 | 40952 | Grating Disc Complete Assembly - 4mm Holes for 40619 | 02201CD | 73661 | Rubber Foot D 12x7.5 for 40619 | 02343 |
| 73608 | Grooved Pin 8x55 for 40619 | 02137 | 40953 | Grating Disc Complete Assembly - 6mm Holes for 40619 | 02201DD | 73662 | Disc Washer for 40619 | 02345 |
| 73609 | Complete Grater Housing for 40619 | 02140 | 40954 | Grating Disc Complete Assembly - 8mm Holes for 40619 | 02201ED | 73664 | Complete Motor Single Phase 110-120V 60Hz for 40619 | 02350B |
| 73610 | Detection Assembly for Drawer for 40619 | 02145 | 40955 | Grating Disc Complete Assembly - Parmesan for 40619 | 02201FD | 73665 | Complete Front Flange for 40619 | 02352 |
| 73611 | Drawer Contact Switch Holder for 40619 | 02146 | 40956 | Grating Disc Complete Assembly - Fondue for 40619 | 02201GD | AC420 | Complete Rotor with Fan for 40619 | 02361 |
| 73612 | Micro Switch for 40619 | 02147 | 40665 | Locking Screw for 40619 | 02205 | AC421 | Fan for 40619 | 02363 |
| 73613 | Screw for 40619 | 02148 | 73637 | V Ring Gasket V22 for 40619 | 02210 | AC422 | Complete Stator Winding 110V 60Hz for 40619 | 02365B |
| AC413 | Washer D3 for 40619 | 02149 | 73639 | Bearing 6202 for 40619 | 02303 | AC423 | Stator Only Single Phase 110V 60Hz for 40619 | 02366B |
| 73614 | Nut H M4 Zn for 40619 | 02151 | AC415 | Bearing Washer for 40619 | 02304 | AC424 | Complete Bottom Plate 220V 50Hz for 40619 | 02402 |
| 73615 | Washer AZ 4 for 40619 | 02152 | 73640 | Chromed Bearing Washer for 40619 | 02312 | AC425 | Bottom Plate Only (Old) for 40619 | 02403 |
| 73616 | Safety Lever for 40619 | 02153 | 73641 | Screw H 4x10 for 40619 | 02313 | AC426 | Rubber Foot D 22x10 for 40619 | 02406 |
| AC414 | Washer 4x14 Zn for 40619 | 02154 | AC416 | Bearing 6202 for 40619 | 02314 | 73666 | Washer 5x12 for 40619 | 02407 |
| 73617 | Safety Lever Spring for 40619 | 02155 | 73643 | Complete Stator (Winding) 110V 60Hz (or 220V 60Hz) for 40619 | 02315B | 73668 | Starting Relay 100-120V 50/60HZ and 220-240V 60Hz for 40619 | 02409B |
| 73618 | Safety Lever for 40619 | 02156 | 73645 | Stator only 1 Phase 110V 60Hz (or 220V 60Hz) for 40619 | 02316B | 73669 | Screw CB M4x10 Zn for 40619 | 02410 |
| 73619 | Washer for 40619 | 02157 | 73646 | Rod M6x35 for 40619 | 02317 | 73670 | Nut H M4 Zn for 40619 | 02411 |
| 73620 | Screw 4x8 Zn Auto for 40619 | 02160 | 73647 | Nut H M6 Zn for 40619 | 02318 | 73672 | Capacitor 250 MF 100-120V 50/60Hz for 40619 | 02412B |
| 73621 | Holding Assembly for Lever Safety Detection for 40619 | 02165 | 73648 | Washer 6x18 for 40619 | 02319 | 73673 | Capacitor Ring for 40619 | 02413 |
| 73622 | Microswitch Holding Plate for 40619 | 02166 | 73649 | Pin 3x5 for 40619 | 02323 | 73674 | Screw CB M4x20 Zn for 40619 | 02414 |
| 73623 | Micro Switch for 40619 | 02167 | 73650 | Rear Flange for 40619 | 02324 | 73676 | Power Cord with USA Plug for 40619 | 02419B |
| 73624 | Screw for 40619 | 02168 | 73651 | Front Flange for 40619 | 02327 | 73677 | Screw H 4.2x12.7 Zn Auto for 40619 | 02422 |
| 73625 | Washer for 40619 | 02172 | 73653 | Assembling Threaded Rod M5x147 for 40619 | 02329 | 73678 | Rubber Foot D25x15 for 40619 | 02430 |
| 73626 | Lever Safety Detection Axle for 40619 | 02173 | 73654 | Fan for 40619 | 02330 | 73679 | Painted Base Only for 40619 | 02431 |
| 73627 | Detection Pin End for 40619 | 02174 | AC417 | Screw CB M4x10 Zn (Old) for 40619 | 02332 | 73680 | Bottom Plate for 40619 | 02432 |
| 73628 | Lever Detection Assembly for 40619 | 02175 | AC418 | Spacer D 16x20x35 (Before 2009) for 40619 | 02334 | 73681 | Screw CBLZ 5.5x16 for 40619 | 02433 |
| 73629 | Safety Spring Plate for 40619 | 02177 | AC419 | Assembling Threaded Rod M5 for 40619 | 02335 | 73682 | Screw H M5x12 Zn Autotar for 40619 | 02434 |
| 73630 | Washer for 40619 | 02179 | 73655 | Cap Nut H M5 Zn for 40619 | 02336 | 73684 | Special On-Off Multifunction Switch D855 8A115V for 40619 | 02435B |
| 73631 | Screw 4X8 Zn Auto for 40619 | 02180 | 73656 | Stainless Steel Motor Protector for 40619 | 02337 | 73685 | Cap D12.2x6.2 Black for 40619 | 02436 |

Parts Breakdown

Model Santos 02 40619

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|---|----------|----------|---|----------|----------|---|----------|
| AC427 | Membrane + Plastic Tally Assembly for 40619 | 02437 | AC428 | Capacitor 150 μ F Diam 46 for 40619 | 02447 | 40667 | Grater Drawer for 40619 | 02502 |
| 73687 | Complete Bottom Plate 110V for 40619 | 02440B | AC429 | Capacitor Ring D46 for 40619 | 02448 | 73691 | Screw FS M4x10 Stainless Steel for 40619 | 02503 |
| 73688 | Washer AZ 4 Zn for 40619 | 02441 | AC430 | Complete Base 120V 60Hz for 40619 | 02450B | AC431 | Special Key for Cheese Grater (Before 2009) for 40619 | 02901 |