


# Parts Breakdown

Model DW-CN-0050 41871



# Parts Breakdown

## Model DW-CN-0050 41871

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
60729	Top Glass for 41871	1	61246	Wire Clip Holder for 41871	23	78097	Baffle for 41871	35
78036	Door Hinge for 41871	3	61245	Wire Clip Cover for 41871	24	78098	Drawer for 41871	36
78110	Door Glass for 41871	4	78121	Plug-Type Fixer for 41871	25	60748	Baseboard for 41871	37
78035	Handle for 41871	5	60741	Power Line for 41871	26	78134	Left Top Bushing for 41871	41
78034	Nail for Glass for 41871	6	79291	Wire Clip for 41871	27	78135	Left Mid-Bushing for 41871	42
78077	Shelf for 41871	7	30597	Switch for 41871	28	60751	Glass Bracket for 41871	43
60735	Water Receiver for 41871	8	60509	Indicating Light for 41871	29	60752	Right Top Bushing for 41871	44
60736	Side Glass for 41871	9	71640	Temperature Thermostat for 41871	30	78137	Right Mid-Bushing for 41871	45
78081	Front Panel for 41871	17	60181	Adjustable Feet for 41871	31	78138	Lower Bushing for 41871	46
60738	Heating Element for 41871	18	71662	Control 125°C for 41871	32	60755	Grill for 41871	47
78083	Rear Panel for 41871	20	71661	Control 150°C for 41871	33	60756	14mm Protecting Coil for 41871	48
78056	Cable Clip Fixer for 41871	22	78061	Probe Pressing Plate for 41871	34			