


# Parts Breakdown

Model DW-CN-0080-L 41872



# Parts Breakdown

## Model DW-CN-0080-L 41872

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
78027	Decorative Frame for 41872	1	78042	Right Panel for 41872	16	78056	Cable Clip Fixer for 41872	31
78028	Top Glass for 41872	2	69097	Heating Element Hanger 1 for 41872	17	61246	Wire Clip Holder for 41872	32
78030	Top Glass Base A for 41872	3	60214	Power Line for 41872	18	61245	Wire Clip Cover for 41872	33
78029	Top Glass Base B for 41872	4	79291	Wire Clip for 41872	19	71661	Control 150°C for 41872	34
78031	Shelf for 41872	5	70688	Switch for 41872	20	71662	Control 125°C for 41872	35
69088	Side Glass for 41872	6	60218	Indicator Light for 41872	21	78061	Probe Pressing Plate for 41872	36
78033	Door Glass for 41872	7	71640	Temperature Thermostat for 41872	22	78062	Plug-Type Fixer for 41872	37
78034	Nail for Glass for 41872	8	69095	Double-Face Protective Ring for 41872	23	78063	Rear Panel for 41872	38
78035	Handle for 41872	9	78050	Baffle for 41872	24	69096	Heating Element for 41872	39
78036	Door Hinge for 41872	10	60181	Adjustable Feet for 41872	25	78043	Heating Element Frame 2 for 41872	40
69091	A-Pillar for 41872	11	78052	Baseboard for 41872	26	60735	Water Receiver for 41872	41
69092	B-Pillar for 41872	12	78053	Electric Box for 41872	27	78066	Front Panel for 41872	42
69093	LED for 41872	13	78054	Electric Cover for 41872	28	78067	Left Panel for 41872	43
69094	LED Separator for 41872	14	78055	Drawer for 41872	29	78068	Grill for 41872	44
78041	Shelf Frame for 41872	15	60145	#6 Driver for 41872	30			