


# Parts Breakdown

Model DW-CN-0115-L 41873



# Parts Breakdown

## Model DW-CN-0115-L 41873

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
78027	Decorative Frame for 41873	1	78042	Right Panel for 41873	16	78056	Cable Clip Fixer for 41873	31
78028	Top Glass for 41873	2	69097	Heating Element Hanger 1 for 41873	17	61246	Wire Clip Holder for 41873	32
78030	Top Glass Base A for 41873	3	69098	Power Line for 41873	18	61245	Wire Clip Cover for 41873	33
78029	Top Glass Base B for 41873	4	79291	Wire Clip for 41873	19	71661	Control 150°C for 41873	34
78031	Shelf for 41873	5	70688	Switch for 41873	20	71662	Control 125°C for 41873	35
78032	Side Glass for 41873	6	60218	Indicator Light for 41873	21	78061	Probe Pressing Plate for 41873	36
78033	Door Glass for 41873	7	71640	Temperature Thermostat for 41873	22	78062	Plug-Type Fixer for 41873	37
78034	Nail for Glass for 41873	8	69095	Double-Face Protective Ring for 41873	23	78063	Rear Panel for 41873	38
78035	Handle	9	78050	Baffle for 41873	24	69096	Heating Element for 41873	39
78036	Door Hinge for 41873	10	60181	Adjustable Feet for 41873	25	78043	Heating Element Frame 2 for 41873	40
78037	Pillar A for 41873	11	78052	Baseboard for 41873	26	60735	Water Receiver for 41873	41
78038	Pillar B for 41873	12	78053	Electric Box for 41873	27	78066	Front Panel for 41873	42
78039	LED Light for 41873	13	78054	Electric Cover for 41873	28	78067	Left Panel for 41873	43
78040	LED Partition for 41873	14	78055	Drawer for 41873	29	78068	Grill for 41873	44
78041	Shelf Frame for 41873	15	60145	#6 Driver for 41873	30			