


Parts Breakdown

Model FW-CN-0100-C 43121



Parts Breakdown

Model FW-CN-0100-C 43121

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
60101	Decorating Gasket of Nut for 43121	1	71662	Thermostat 125 Degree for 43121	15	65465	Heating Tube Bracket for 43121	29
60102	Nut Decorating Parts for 43121	2	60497	Thermostat 95 Degree for 43121	16	60735	Water Tray for 43121	30
64883	Top Glass for 43121	3	65457	Wire Supporter Baseboard for 43121	17	65466	Frame for 43121	31
60103	Big Gasket of Nut for 43121	4	60211	Rubber Feet for 43121	18	61245	Wire Clip Cover for 43121	32
65452	Rear Glass Support 2 for 43121	5	65459	Head Cover for 43121	19	61246	Wire Clip Holder for 43121	33
64878	Glass Mirror for 43121	6	65460	Top Light Cover for 43121	20	65451	Fixed Seat for Cable Clamp for 43121	34
65453	Rear Glass Support 1 for 43121	7	65444	Lamp Holder for 43121	21	65450	Aluminum Foil Heater for 43121	35
65435	Lower Bracket of Heating Tube for 43121	8	65461	Tungsten Lamp for 43121	22	60511	Power Line for 43121	36
65454	Outside Pillar for 43121	9	65462	Reflector for 43121	23	79291	Wire Clip for 43121	37
65455	Inside Pillar for 43121	10	65447	Upper Bracket of Heating Tube for 43121	24	60508	Switch for 43121	38
65456	Side Glass for 43121	11	65448	Heating Tube for 43121	25	78061	Probe Pressing Plate for 43121	39
78062	Plug-Type Fixer for 43121	12	60178	1/2 GN Pan for 43121	26	71640	Temperature Thermostat for 43121	40
65457	Wire Supporter for 43121	13	65463	Mid-Frame for 43121	27			
65440	Fixed Plate for Heating Panel for 43121	14	65464	Baseboard of Mid-Frame for 43121	28			