


Parts Breakdown

Model FW-CN-0032 43623



Parts Breakdown

Model FW-CN-0032 43623

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
62106	Chamber Cover for 43623	1	62115	Outer Tray Plate for 43623	11	62124	Power Cord and Strain Relief for 43623	20
62107	Chamber Support for 43623	2	62116	Knob for 43623	12	62125	Heating Element Support for 43623	22
62108	Chamber Base for 43623	3	62117	Control Panel for 43623	13	62126	Left Slide Plate for Tray Cover for 43623	23
62109	Tray Cover for 43623	4	62118	Indicator Light for 43623	14	62127	Bottom Tray Plate Cover for 43623	24
62110	Full Size Food Pan for 43623	6	62119	Switch for 43623	15	62128	Right Slide Plate for Tray Cover for 43623	25
62111	Tray Support Frame for 43623	7	62120	Thermostat for 43623	16	62129	Chamber Boarding for 43623	26
62112	Tray Support for 43623	8	62121	Heating Element for 43623	17	62130	Screw / Bearing for 43623	27
62113	Handle for 43623	9	62122	Bakelite Foot with Rubber Insert and Screw for 43623	18	62131	Body Shell for 43623	28
62114	Inner Tray Plate for 43623	10	62123	Bottom Plate for 43623	19			