


# Parts Breakdown

Model RS-CN-0860 46471



# Parts Breakdown

## Model RS-CN-0860 46471

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AE324	Upper Door Frame Fixer for 46471	1	AE352	Fan Motor for 46471	29	AE380	Water Tray for 46471	58
AE325	Right Door Frame for 46471	2	AE353	Vent Tray for 46471	30	AE381	Motor Bracket for 46471	59
AE326	Door Seal for 46471	3	AE354	Evaporator Cover for 46471	31	30624	Dry Filter for 46471	60
AE327	Upper and Bottom Outer Frames for 46471	4	AE355	Evaporator for 46471	32	AE382	Condenser for 46471	61
AE328	Door Glass for 46471	5	AE356	Evaporator Frame for 46471	33	AE383	Return Air Tube for 46471	62
AE329	Door Frame Sets for 46471	6	AE357	Temperature Probe for 46471	34	AE384	Display Panel for 46471	63
AE330	Brace Connecting Pin for 46471	7	AE358	Compressor Protect Probe for 46471	35	AE385	Compressor for 46471	64
AE331	Brace Left Connecting Plate Threaded Hole for 46471	8	AE359	Defrost Probe for 46471	36	AE386	Left Glass for 46471	65
AE332	Brace Connecting Plate Seat for 46471	9	AE360	Power Fixing Board for 46471	37	AE387	Price Tag for 46471	66
AE333	Brace Right Connecting Plate for 46471	10	AE361	Main Control Box for 46471	38	AE388	Metal Shelf Support for 46471	67
AE334	Arc Left Stiffening Plate for 46471	11	AE362	LED Transformer for 46471	39	AE389	Shelf Glass Bottom for 46471	68
AE335	Left Door Frame for 46471	12	AE363	Upper Cover of Main Board Fixing Box Large for 46471	40	AE390	Shelf Glass Middle for 46471	69
AE336	Power Cord Black for 46471	13	AE364	Bottom Cover of Main Board Fixing Box Large for 46471	42	AE391	Shelf Glass Top for 46471	70
AE337	Arc Door Top Decoration Plate for 46471	14	AE365	Main Control Box Cover for 46471	43	AE392	Power Cord for 46471	71
AE338	Arc Door Top Plate for 46471	15	AE366	Right Glass for 46471	44	AE393	Back Grill for 46471	72
AE339	LED Lights for 46471	16	AE367	Nut Gasket for 46471	45	62912	Switch for 46471	73
AE340	Right Top Shelf Holder for 46471	17	AE368	Nut Decoration for 46471	46	AE394	Digital Controller for 46471	74
AE341	Brace Holder for 46471	18	AE369	Decoration Nut Gasket for 46471	47	AE395	Left and Right Outer Frame for 46471	75
AE342	Arc Right Stiffening Plate for 46471	19	AE370	Front Condenser Ventilation Plate for 46471	48	AE396	Left Bottom Shelf Holder for 46471	76
AE343	Right Arc Door Frame for 46471	20	AE371	Front Panel for 46471	49	AE397	Left Middle Shelf Holder for 46471	77
AE344	Right Middle Shelf Holder for 46471	21	AE372	Front Black Decorative Strip for 46471	50	AE398	Left Top Shelf Holder for 46471	78
AE345	Arc Door Glass for 46471	22	AE373	Castor for 46471	51	AE399	Pulley Assembly for 46471	79
AE346	Right Bottom Shelf Holder for 46471	23	AE374	Castor with Brake for 46471	52	AE400	Bottom Door Frame for 46471	80
AE347	Arc Door Handle Frame for 46471	24	AE375	Underframe Assembly for 46471	53	AE401	Door Gasket for 46471	81
AE348	Gas Spring for 46471	25	AE376	Side Glass Mate for 46471	54	AE402	Left Door Frame for 46471	82
AE349	Vent Tray Glass Support Plate 1 for 46471	26	AE377	Left and Right Side Glass Support Plate for 46471	55	AE403	Top Upper Door Frame for 46471	83
AE350	Vent Tray Glass Support Plate 2 for 46471	27	AE378	Fan Motor for 46471	56	AE404	Base Glass for 46471	84
AE351	Fan Net Cover for 46471	28	AE379	High Pressure Copper Tube for 46471	57			