

Parts Breakdown

Model VP-NL-0063-L 50002

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
35423	Vacuum Cover Complete for 50002	0010	35255	Distribution Block 4DVB/VP 3/8"-1/4"-4 for 50002	1130	30005	Hexagon Screw M6x12 Din933 A2 for 50002	1580
35290	Sight Glass (380x280x20) for 50002	0020	35249	Elbow Coupling 10x1/4" for 50002	1140	27837	Hose (O2) Drago 6x13 for 50002	1600
35105	Sil.Profile Lid Gasket 8mm 60°SH/25MTR for 50002	0030	35258	Blind Plug 3/8" MS/VN for 50002	1150	35253	Closing Plug Silicon Holder for 50002	1610
35299	Handle GN-565-26-192-SW 800 for 50002	0040	35254	Reducing Nipple 1/2"x3/8" for 50002	1160	35251	Hexagon Nut M8x1 Low Din439B for 50002	1620
35427	Plug GN-340 for 50002	0050	35457	T-Piece 1/2x1/2x1/2 BU/BU/BI for 50002	1170	35250	Gas Nozzle Universal for 50002	1630
35428	Hex.Socket Head Cap Screw M12x35 Din912 A2 for 50002	0060	35252	Gas Valve for Gas Distribute Pot for 50002	1180	35488	3-Way Valve Soft-Air New for 50002	1640
35298	Cable Gland M20x1,5 Brass for 50002	0070	15722	Vacuum Valve without Decompr.Head 32mm for 50002	1190	27820	Right Hose Coupling 1/8"x6 Ext. for 50002	1650
35430	Spring Ring Cheese Head M12 Din7980 A2 for 50002	0080	15723	Decompress Head Vacuum Valve 32mm for 50002	1200	35490	Single Banjo Bolt 1/8" for 50002	1660
35431	Sealing Washer 0251796/0251797 for 50002	0100	35282	T-Screw-in Hose Coupling 1/8"x6 Ext. for 50002	1210	35491	Sealing Mechanism for 50002	3010
35432	Slotted Cheese Head Screw M4x8 A2 Din84 for 50002	0130	15751	Decompress Filter 1/2" for 50002	1220	35492	Spacer Sil.Holder Gas 35mm for 50002	3020
35433	Castle Washer M4 for 50002	0140	41483	Filler Plate 1"/25mm for 50002	1230	35493	Silicon Holder for 50002	3030
35300	Hexagon Screw M8x20 Din933 A2 for 50002	0150	35464	Filter Gauze Clip Ring for 50002	1240	35494	Silicon Holder for 50002	3035
35301	Castle Washer Red Copper M8 for 50002	0170	35465	Filter for 50002	1250	35365	Mounting Screw Holing Block HD-03 for 50002	3040
35436	Shaft Journal Cover for 50002	0180	35466	PVC Nipple BEA 40x32x1 for 50002	1270	35355	Cable Clip 1x10mm Din72571 for 50002	3050
35437	Bearing Cover Double Chamber for 50002	0190	35467	PVC Tube Round 32 L=80mm for 50002	1280	35497	Pressure Beam for 50002	3060
35438	Parallel Rod for 50002	0200	35468	Limit Switch with Cable for 50002	1350	35352	Cable Clamp 1x12mm Din7257 for 50002	3070
35439	Clamping Profile Parallel Rod for 50002	0210	35469	Hex.Socket Head Cap Screw M5x25 Din912 A2 for 50002	1360	27836	Connecting Piece T-Piece 6mm for 50002	3080
35440	Hex.Socket Head Cap Screw M8x30 Din912 A2 for 50002	0220	35249	Elbow Coupling 10x1/4" for 50002	1400	35500	Hexagon Screw M8x70 Din933 A2 for 50002	3085
35441	Vacuum Chamber Complete for 50002	1010	35471	Non-Return Valve 1/2 for 50002	1420	35501	Hexagon Screw M8x70 + M4 for 50002	3090
35442	Clamping Plate Vacuum Chamber for 50002	1020	35256	Air Pressure Hose Blue 10x8 for 50002	1460	35502	Seal Beam DS/1/655 for 50002	3100
27827	Flat Washer M10 D9021 A2 for 50002	1030	35247	Blind Stopper + O-Ring 1/4" MS/VN for 50002	1475	35503	Seal Beam TS/1/655 for 50002	3110
35444	Hexagon Screw M10x16 Din933 A2 for 50002	1040	15716	3-Way Valve for 50002	1480	35504	Seal Beam S2/1/655 for 50002	3115
35445	Parallel Axle for 50002	1050	30015	Square Hose Coupling 1/4"x6 Ext. for 50002	1510	35505	Seal Beam 8mm/1/655 for 50002	3120
35446	Hex.Socket Head Cap Screw M10x30 Din912 VZ for 50002	1060	35476	Square Hose Coupling 1/4"x8 Ext. for 50002	1520	27788	Adj.Screw/Soc.Head M6x25 Din916 A2 for 50002	3130
35447	Castle Washer M10 for 50002	1070	35477	Adj.Sxrew/Soc.Head M4x20 Din916 A2 for 50002	1525	35507	Holing Block Silicon Holder HD-03 for 50002	3140
35448	Support Bearing for 50002	1080	34998	Flat Washer M4 D9021 A2 for 50002	1530	35364	O-Ring 27x2.5 for 50002	3150
35449	Bearing Ring PAF-20115-P10 for 50002	1090	35411	Hexagon Nut M4 Din934 A2 for 50002	1540	35509	Tube Alu 10x1mm L=540mm for 50002	3160
35450	Switch Disc 3 for 50002	1100	35480	Hose Clip ABA 11-17mm for 50002	1550	35447	Castle Washer M10 for 50002	3180
35451	Switch Plate Double Chamber for 50002	1110	35481	Hex.Socket Head Cap Screw M5x16 Din912 A2 for 50002	1560	35372	Castle Washer M8 for 50002	3190
35452	Adjusting Ring 30mm for 50002	1120	27786	Flat Washer M6 D9021 A2 for 50002	1570	35512	Compression Spring Sealing Mechanism for 50002	3200

Parts Breakdown

Model VP-NL-0063-L 50002

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
35513	Vacuum Bag Holder for 50002	3210	35539	Elbow 1/2" Ext/Ext Brass Nickle for 50002	4160	35399	Upper Sticker Turbovac 03 for 50002	9051
35105	Sil.Profile Lid Gasket 8mm 60°SH/25MTR for 50002	3220	35413	Elbow 1/4" Int Brass for 50002	4170	35400	Packing Cover Control + Glue-Layer for 50002	9060
34998	Flat Washer M4 D9021 A2 for 50002	3230	35261	Brass Hose Coupling 1/4"x8 Ext. for 50002	4180	30010	Brass Nut 1/4" for 50002	9070
35383	Slotted Cheese Head Screw M4x16 A2 Din84 for 50002	3240	35248	Hose Coupling 1/2"x10 Ext. for 50002	4190	35402	Square Hose Coupling 1/8"x4 Ext. for 50002	9080
15842	Silicone T-Profil 40 Shore One Meter for 50002	3490	35481	Hex.Socket Head Cap Screw M5x16 Din912 A2 for 50002	4240	35403	Plastic Checknut PG 16 for 50002	9090
30005	Hexagon Screw M6x12 Din933 A2 for 50002	3580	27782	Hexagon Flangenut M5 Din6923 A2 for 50002	4250	35404	Cover Control Box for 50002	9100
27824	Castle Washer M6 for 50002	3590	35387	Vac Pump 040-132 230/400-3-50 E for 50002	5010	35571	Cross Recessed Raised Cheese Head Screw M3.5x10 for 50002	9110
35520	Tube STST 10x1x60mm for 50002	3600	35388	Hose Clip ABA 32-44mm for 50002	5040	35406	Cable Gland PG16 IP65 Plastic for 50002	9120
35521	Seal Bag 2" L=480mm for 50002	3620	15833	PVC Suction Hose HNA-32x42mm for 50002	5050	35407	Sealing Washer 0-1/4 for 50002	9130
35353	Self Tapping Screw PIAS 3.5x9.5 for 50002	3660	35390	Pipe Nipple Half 1/2 1" for 50002	5060	35408	Reducing Ring 1/4"x1/8" for 50002	9140
35523	Bottom Section for 50002	4000	27814	Hexagon Nut M8 Din934 A2 for 50002	5070	27819	Square Hose Coupling 1/8"x6 Ext for 50002	9150
35369	Swivel Castor Black ST.ST. 100m for 50002	4010	35391	Adj.Screw/Soc.Head M8x25 Din916 A2 for 50002	5080	34998	Flat Washer M4 D9021 A2 for 50002	9160
35368	Spring Control Box for 50002	4020	35219	Flat Washer M8 D9021 A2 for 50002	5090	35411	Hexagon Nut M4 Din934 A2 for 50002	9170
35219	Flat Washer M8 D9021 A2 for 50002	4030	35552	Reducing Ring 1 1/4"x1" for 50002	5110	35578	Locking Profile Control Basic for 50002	9180
35372	Castle Washer M8 for 50002	4040	62687	Control Unit DS 3-400V 4A 2x24V for 50002	8000	35579	Vacuum Meter 40mm for 50002	9190
35220	Hexagon Screw M8x10 Din933 A2 for 50002	4050	27782	Hexagon Flange Nut M5 Din6923 A2 for 50002	8010	35413	Elbow 1/4" Int Brass for 50002	9200
27814	Hexagon Nut M8 Din934 A2 for 50002	4060	35555	Cover Switch Box for 50002	8020	29997	Brass Hose Coupling 1/4"x6 Ext. for 50002	9210
35530	Stud M8x160 DK for 50002	4070	35556	Seal Cord C1-08 for 50002	8230	35415	Plug Blac R5 for 50002	9310
35531	Pipe 13x1,5x34mm Stainless Steel 304 for 50002	4080	35557	Valve Cord CC2-06 for 50002	8240	35416	Plug Blac R6 for 50002	9320
35532	Tension Spring for 50002	4090	35329	Pump Cord CM4-09 for 50002	8250	35417	Plug Blac R10 for 50002	9330
35533	Hexagon Screw M8x400 A2 for 50002	4100	35559	Microcellular Rubber 4mm Black for 50002	8330	15712	Hydraulic Oil for 3-Phase Vacuum Pump (060510) for 50002	9400
35534	Spring Axle Double Chamber for 50002	4110	35394	Control 03-Turbovac for 50002	9010	27795	Sticker Tension Triangle for 50002	9420
35298	Cable Gland M20x1,5 Brass for 50002	4120	35395	Control Turbovac Basic for 50002	9011	27794	Sticker Machine Type for 50002	9430
35375	Nut M20x1.5 MS for 50002	4130	35396	Packing Control + Glue-Layer for 50002	9020	35223	Sticker 19x38 Yellow for 50002	9440
35537	Self Locking Hexagon Nut M8 Din985 A2 for 50002	4140	15780	Switch-Disconnecter Tripolar 25A Front for 50002	9040	35224	Sticker 98x65 Yellow for 50002	9450
35372	Castle Washer M8 for 50002	4150	35398	Control Panel Holder Turbovac for 50002	9050			