

INSTRUCTION MANUAL

Cheese Grater

Item	19921
Model	GR-IT-1491-B



⚠ Warning!

Before you begin using your appliance, **PLEASE READ AND UNDERSTAND THIS DOCUMENT CAREFULLY** before installing, operating, maintaining, or servicing.

There are many important safety messages in this manual and on your appliance. Always read all safety messages.

Failure to do so can result in appliance failure, property damage, serious injury or death. Appliance failure, injury or property damage due to improper installation is not covered by warranty.

✋ Stop!

DO NOT RETURN THIS PRODUCT TO THE STORE!

For questions or assistance with this product, call TRENTO Toll free: **1-833-487-3686** or visit the support section from our website, www.trentoequipment.com

Version: Revised - 07/03/2025



WARRANTY
PARTS & LABOUR



TABLE OF CONTENTS

Section	Page
General Information -----	3 - 4
Safety and Warranty -----	4 - 6
Technical Specifications -----	6
Installation -----	6 - 7
Operation -----	7 - 9
Maintenance -----	9
Troubleshooting -----	10
Parts Breakdown -----	11 - 12
Electrical Schematics -----	13
Notes -----	14
Warranty Registration -----	15

GENERAL INFORMATION

Omcane Manufacturing and Distributing Company Inc., Food Machinery of America, Inc. dba Omcan and Omcan Inc. are not responsible for any harm or injury caused due to any person's improper or negligent use of this equipment. The product shall only be operated by someone over the age of 18, of sound mind, and not under the influence of any drugs or alcohol, who has been trained in the correct operation of this machine, and is wearing authorized, proper safety clothing. Any modification to the machine voids any warranty, and may cause harm to individuals using the machine or in the vicinity of the machine while in operation.

CHECK PACKAGE UPON ARRIVAL

Upon receipt of an Omcan shipment please inspect for external damage. If no damage is evident on the external packaging, open carton to ensure all ordered items are within the box, and there is no concealed damage to the machine. If the package has suffered rough handling, bumps or damage (visible or concealed), please note it on the bill of lading before accepting the delivery and contact Omcan within 24 hours, so we may initiate a claim with the carrier. A detailed report on the extent of the damage caused to the machine must be filled out within three days, from the delivery date shown in the shipping documents. Omcan has no recourse for damaged products that were shipped collect or third party.

Before operating any equipment, always read and familiarize yourself with all operation and safety instructions.

Omcan would like to thank you for purchasing this machine. It's of the utmost importance to save these instructions for future reference. Also save the original box and packaging for shipping the equipment if servicing or returning of the machine is required.

Omcan Fabrication et distribution Companie Limité et Food Machinery d'Amerique, dba Omcan et Omcan Inc. ne sont pas responsables de tout dommage ou blessure causé du fait que toute personne ait utilisé cet équipement de façon irrégulière. Le produit ne doit être exploité que par quelqu'un de plus de 18 ans, saine d'esprit, et pas sous l'influence d'une drogue ou d'alcool, qui a été formé pour utiliser cette machine correctement, et est vêtu de vêtements de sécurité approprié. Toute modification de la machine annule toute garantie, et peut causer un préjudice à des personnes utilisant la machine ou des personnes à proximité de la machine pendant son fonctionnement.

VÉRIFIEZ LE COLIS DÈS RÉCEPTION

Dès réception d'une expédition d'Omcan veuillez inspecter pour dommages externes. Si aucun dommage n'est visible sur l'emballage externe, ouvrez le carton afin de s'assurer que tous les éléments commandés sont dans la boîte, et il n'y a aucun dommage dissimulé à la machine. Si le colis n'a subi aucune mauvaises manipulations, de bosses ou de dommages (visible ou cachée), notez-le sur le bond de livraison avant d'accepter la livraison et contactez Omcan dans les 24 heures qui suivent, pour que nous puissions engager une réclamation auprès du transporteur. Un rapport détaillé sur l'étendue des dommages causés à la machine doit être rempli dans un délai de trois jours, à compter de la date de livraison indiquée dans les documents d'expédition. Omcan n'a aucun droit de recours pour les produits endommagés qui ont été expédiées ou cueillies par un tiers transporteur.

Avant d'utiliser n'importe quel équipement, toujours lire et vous familiariser avec toutes les opérations et les

GENERAL INFORMATION

consignes de sécurité.

Omcan voudrais vous remercier d'avoir choisi cette machine. Il est primordial de conserver ces instructions pour une référence ultérieure. Également conservez la boîte originale et l'emballage pour l'expédition de l'équipement si l'entretien ou le retour de la machine est nécessaire.

Omcan Empresa De Fabricacion Y Distribucion Inc. Y Maquinaria De Alimentos De America, Inc. dba Omcan y Omcan Inc. no son responsables de ningun daño o perjuicio causado por cualquier persona inadecuada o el uso descuidado de este equipo. El producto solo podra ser operado por una persona mayor de 18 años, en su sano juicio y no bajo alguna influencia de droga o alcohol, y que este ha sido entrenado en el correcto funcionamiento de esta máquina, y ésta usando ropa apropiada y autorizada. Cualquier modificación a la máquina anula la garantía y puede causar daños a las personas usando la máquina mientras esta en el funcionamiento.

REVISE EL PAQUETE A SU LLEGADA

Tras la recepcion de un envio Omcan favor inspeccionar daños externos. Si no hay daños evidentes en el empaque exterior, Habra el carton para asegurarse que todos los articulos solicitados estén dentro de la caja y no encuentre daños ocultos en la máquina. Si el paquete ha sufrido un manejo de poco cuidado, golpes o daños (visible o oculto) por favor anote en la factura antes de aceptar la entrega y contacte Omcan dentro de las 24 horas, de modo que podamos iniciar una reclamación con la compañía. Un informe detallado sobre los daños causados a la máquina debe ser llenado en el plazo de tres días, desde la fecha de entrega que se muestra en los documentos de envío. Omcan no tiene ningun recurso por productos dañados que se enviaron a recoger por terceros.

Antes de utilizar cualquier equipo, siempre lea y familiarizarse con todas las instrucciones de funcionamiento y seguridad.

Omcan le gustaría darle las gracias por la compra de esta máquina. Es de la mayor importancia para salvar estas instrucciones para futuras consultas. Además, guarda la caja original y el embalaje para el envío del equipo si servicio técnico o devolución de la máquina que se requiere.

SAFETY AND WARRANTY

FORBIDDEN USES

The machine must only be used for the purposes expressly intended by the manufacturer. In particular:

- Do not use the machine to grate food products other than cheese, bread and the like.
- Do not use the machine if it has not been correctly installed with all the protections intact and correctly assembled to avoid the risk of severe injury.
- Do not access electrical components without having previously disconnected the machine: risk of electrocution.

SAFETY AND WARRANTY

- Do not work products that are bigger than what can be totally contained in the feeding inlet.
- Do not wear clothes that do not comply with safety regulations. Consult your employer for safety regulations and the safety devices required.
- Do not use the machine if it is not working correctly.
Before starting the machine make sure that any dangerous condition has been appropriately eliminated. If a fault occurs, stop the machine and notify persons in charge of maintenance.
- Do not allow unauthorized personnel to carry out work on the machine.
In the event of emergency treatment due to an accident caused by electrical shock, first remove the victim from the conductor (as he will be unconscious).
This operation is dangerous as the victim is a conductor in this case and touching him could cause electrocution.
Therefore disconnect the contact directly from the power supply valve or, if this is not possible, distance the victim using insulating material (wooden or pvc sticks, fabric, leather, etc.).
A doctor should be promptly called and the patient should be taken to the hospital.

ATTENTION!

Do not intervene on electrical parts while the machine is connected to the power supply. Observe the warnings on the plates. Failure to observe them can cause serious injury. Make sure the plates are always fitted and readable. If not, fit or replace them.

ATTENTION!

Before using the machine make sure that the devices are correctly positioned and in perfect working order. At the beginning of each work shift check that they are fitted and working properly; if not, notify the head of maintenance.

MICRO SWITCH ON THE LEVER

The machine is outfitted with a micro switch on the lever of the inlet. This works by blocking the machine when the lever remains lifted or the inlet is completely disassembled.

MICRO SWITCH ON THE CONTAINER

The machine is outfitted with a micro switch on the plexiglass container. When the container is extracted the machine stops.

ATTENTION!

Do not tamper with the safety devices in any way.

RESIDENTIAL USERS: vendor assumes no liability for parts or labor coverage for component failure or other damages resulting from installation in non-commercial or residential applications. The right is reserved to deny shipment for residential usage; if this occurs, you will be notified as soon as possible.

1 YEAR PARTS AND LABOUR BENCH WARRANTY

Within the warranty period, contact Omcan Inc. at 1-833-487-3686 to schedule a drop off to either an Omcan authorized service depot in the area, or to an Omcan Service warehouse to repair the equipment.

SAFETY AND WARRANTY

Unauthorized maintenance will void the warranty. Warranty covers electrical and part failures, not improper use.

Please see <https://omcan.com/disclaimer> for complete info.

WARNING:

The packaging components are classified as normal solid urban waste and can therefore be disposed of without difficulty.

In any case, for suitable recycling, we suggest disposing of the products separately (differentiated waste) according to the current norms.

DO NOT DISCARD ANY PACKAGING MATERIALS IN THE ENVIRONMENT!

TECHNICAL SPECIFICATIONS

Item Number	19921
Model	GR-IT-1491-B
Product Capacity per Hour	240 lbs. / 108.9 kgs.
Power	2 HP / 1.49 kW
Grater Revolution	1400 RPM
Brake Motor	Yes
Mouth Dimensions	3.7" x 7.5" / 95 x 191mm
Electrical	240V / 60Hz / 1
Weight	74.1 lbs. / 33.6 kgs.
Packaging Weight	86 lbs. / 39 kgs.
Dimensions	20.8" x 13" x 20.4" / 528 x 330 x 518mm
Packaging Dimensions	30" x 26" x 24" / 762 x 660 x 609mm

INSTALLATION

ATTENTION!

The area where you intend to install the machine must be flat and solid. Furthermore, the machine must be positioned with ample space around it. This enables greater maneuverability during working phases and guarantees access for periodic maintenance. Ensure sufficient lighting around the machine to guarantee

INSTALLATION

correct visibility for the machine operator.

MOVING THE MACHINE

ATTENTION!

Lift the machine with a forklift of suitable capacity. Check the stability and positioning of the weight on the forks, especially along uneven, slippery or inclined paths. When moving the machine keep the load as low as possible to guarantee greater stability and visibility. Stabilize the grip by widening the forks of the forklift.

CONNECTION TO THE ELECTRICAL SYSTEM

ATTENTION!

Make sure the electrical source corresponds to the value reported on the identification plate of the machine. Each operation should be carried out only by specialized personnel authorized by the appropriate supervisor. Connect the machine to a network with an efficient floor plug.


Connect the cable to the 240V/60Hz single-phase electrical supply network, inserting a 16-Amp magnetothermic differential switch. For machines with voltages different from those mentioned consult the manufacturer. If the feeding cable needs to be extended, use a cable with the same section as the one supplied by the manufacturer.

OPERATION

RUN GRATER WITH DRY BREAD BEFORE INITIAL USE TO CLEAN IT.

LIST OF COMMANDS

1. Stop push button.
 - Stop push button: black color.
 - Press to stop the machine.
 - The led on the push button lights up only when the stop push button is pressed (4).
2. Start push button.
 - Start push button: gray color.
 - Press to start the machine.
3. Lit indicator of connection to the mains.
 - White color.
 - It indicates the connection of the machine to the network.



OPERATION

START UP AND STOP


ATTENTION!

Check that the feeding line corresponds to the value reported on the identification plate of the machine and that it is outfitted with an efficient floor plug.

1. Put the plug into the electrical outlet.
2. Set the differential switch in position "I". The lit indicator, indicating that the machine is powered, must be illuminated.
3. Press the push button to start and immediately afterwards press the stop one, checking the rotation direction of the roller.

NOTE

The presser must be in a low position.



The roller rotation direction must be the same as the one indicated by the arrow.

CHECKING THE PRESENCE AND EFFICIENCY OF PROTECTIONS AND SAFETIES

1. Micro switch on the lever.

While the machine is running lift the presser until the micro switch intervenes and stops the machine. Keep the presser still in the point in which the micro switch intervenes and check that the space between the loading inlet and the presser is such to block fingers from entering. If this is not the case contact an authorized re-seller or the manufacturer.

2. Micro switch on the lever.

While the machine is running extract the plexiglass container and make sure that the machine stops.

CHECKING THE EFFICIENCY OF THE STOP PUSH BUTTON

While the machine is connected to the power supply and the utensil is moving press the push button.

START UP

- Set the differential switch fitted upstream at "I". The light indicator will light up, indicating that the machine is powered.
- Press the start push button to start the machine.

NOTE

If the presser is in an "open" position the machine will not run, therefore it will have to be lowered.

STOP

- Press the stop push button to stop the running of the machine; the light indicator will remain on to indicate

OPERATION

- that the machine is powered.
- Then set the differential switch installed upstream at "0", in this way disconnecting the machine.

NOTE

Each time a work shift finishes or the machine is left to rest, the differential switch must be left set at "0".

USING THE SIEVE

The extractable sieve "1" in stainless steel enables obtaining a uniformly grated product, avoiding sieving. It must be requested upon ordering the machine.

MAINTENANCE

ATTENTION!

Every maintenance and cleaning operation on the grater must only be done with the machine at a standstill, disconnected from the power supply. The area where maintenance operations are carried out must always be kept clean and dry. Do not allow unauthorized personnel to work on the machine. Any replacement of parts must be made with original spare parts at authorized work shops or directly by the manufacturer.

ATTENTION!

Disconnect the machine from the electrical supply before cleaning it. Do not clean the machine with jets of water. Only use non-toxic detergents, designated for cleaning components for use with food products.

PUTTING OUT OF ORDER


The machine is made of materials such as aluminum, steel and copper; therefore they do not require particular operations for scrapping. Therefore use companies specialized in trash disposal, separating the components according to material.

TROUBLESHOOTING

Problems	Causes	Solutions
The machine does not start.	The differential switch is not set at "0".	Put the switch at "I".
	The presser is in a high position.	Lower the presser.
	The micro switch installed on the grater inlet does not work.	Call technical assistance.
	The start push button does not work.	
	The electrical motor or the electronic card are faulty.	

PARTS BREAKDOWN

ITEM	MODEL
19921	GR-IT-1491-B





PARTS BREAKDOWN

ITEM	MODEL
19921	GR-IT-1491-B

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
18960	Magnet SO Anodized for 19921	1	AM695	Motor. M90L HP 2 B34 4P 230/60 with Thermal Protection & Motor Brake CSA for 19921	18	69210	Indented Washer Din 6798-A D 8E for 19921	37
20262	Magnetic Contactor for 19921	2	69206	Leg Side IS 8/16 for 19921	19	62657	Screw TSPEI Din 7991 M8x20 for 19921	38
AM947	PCB Cutters (Self-Braking) for 19921	3	44917	Handle for 19921	20	69211	Washer Thick Din 9021 D8x32 for 19921	39
AG284	Cable 3x1.50 for 19921	4	66623	Grater Mouth Inox for 19921	21	69212	Screw TCEI Din 912 M6x12 for 19921	40
61604	Strain Relief + Nut for 19921	5	66624	Flange for 19921	22	62661	Hex.Socket Head Cap Screw M6x20 for 19921	41
61603	Nut Ott.Nich.PG 11 for 19921	6	41688	Pin for 19921	24	69213	Screw without Head Din913 M4x16 P.PN for 19921	42
AM948	Key Pad IS-SO for 19921	7	66622	Cover for 19921	25	62662	Screw TE Din 933 M8x16 T.F. for 19921	43
61608	Terminal Comb. BZ for 19921	8	69199	Hull X Casing for 19921	26	69214	Screw TE Din 933 M8x30 T.F. for 19921	44
60396	Stainless Steel On Button with Lamp for 19921	9	69207	Thickness Pressing Sheet of Mouth for 19921	27	69215	Nut Din 934 M3 for 19921	45
60397	Stainless Steel Off Button for 19921	10	69200	Casing Rear Panel for 19921	28	62666	Hex.Nut Din 934 M8 for 19921	46
65421	Magnetic Switch for 19921	11	18959	Plexi Glass Collecting Tray for 19921	30	60079	Self-Locking Nut ES Din 982 M5 High for 19921	47
AM954	Bearing 6005 2RS for 19921	12	41907	Drum for 19921	31	69216	Self Blocking Nut ES Din 982 M8 Upper for 19921	48
AM955	Dist. Plast Card TC22/32 Pol 3mm for 19921	13	69201	Bottom of Casing for 19921	32	69217	Screw Poeliers M4x8 for 19921	49
69203	Rubber Foot for 19921	14	69208	Upper Plastron Mot for 19921	33	69218	Screw Poeliers M5x8 for 19921	50
69204	Plug Cover Hole Flange for 19921	15	69209	Washer Din 125 D3 for 19921	34	60080	Screw Poeliers M5x12 for 19921	51
66642	Handle - New Style/Small (L-94mm) for 19921	16	62648	Blind Nut Din 1587 M5 for 19921	35	37237	16MF Capacitor for 19921	52
60077	Fixing Knob for 19921	17	61583	Nut Din 1587 M6 for 19921	36	68848	Plexi Tray Assembly (Handle with Magnet) for 19921	53

ELECTRICAL SCHEMATICS

ITEM	MODEL
19921	GR-IT-1491-B



NOTES

WARRANTY REGISTRATION

Thank you for purchasing an Trento product. To register your warranty for this product, complete the information below, tear off the card at the perforation and then send to the address specified below. You can also register online by visiting:

Merci d'avoir acheté un produit Trento. Pour enregistrer votre garantie pour ce produit, complétez les informations ci-dessous, détachez la carte au niveau de la perforation, puis l'envoyer à l'adresse spécifiée ci-dessous. Vous pouvez également vous inscrire en ligne en visitant:

Gracias por comprar un producto Trento usted. Para registrar su garantía para este producto, complete la información a continuación, cortar la tarjeta en la perforación y luego enviarlo a la dirección indicada a continuación. También puede registrarse en línea en:

<https://omcan.com/warranty-registration/>

For mailing in Canada

Pour postale au Canada

Por correo en Canadá

For mailing in the US

Pour diffusion aux États-Unis

Por correo en los EE.UU.

TRENTO
PRODUCT WARRANTY REGISTRATION
3115 Pepper Mill Court,
Mississauga, Ontario
Canada, L5L 4X5

TRENTO
PRODUCT WARRANTY REGISTRATION
4450 Witmer Industrial Estates, Unit 4,
Niagara Falls, New York
USA, 14305

or email to: trentoservice@trentoequipment.com



Purchaser's Information

Name: _____

Company Name: _____

Address: _____

Telephone: _____

City: _____ Province or State: _____ Postal or Zip: _____

Email Address: _____

Country: _____

Type of Company: _____

Dealer from which Purchased: _____

Restaurant Bakery Deli

Dealer City: _____ Dealer Province or State: _____

Butcher Supermarket Caterer

Invoice: _____

Institution (specify): _____

Other (specify): _____

Model Name: _____ Model Number: _____

Serial Number: _____

Machine Description: _____

Date of Installation (MM/DD/YYYY): _____

Date of Purchase (MM/DD/YYYY): _____


Would you like to extend the warranty? Yes No

Thank you for choosing Trento | Merci d'avoir choisi Trento | Gracias por elegir Trento



TRENTO IS A SIGNATURE LINE OF PROFESSIONAL
RESTAURANT EQUIPMENT FROM OMCAN OFFERING
PREMIUM EUROPEAN BRANDS TO THE NORTH AMERICAN
MARKET.

Thank you for your purchase!



Follow us on social media
[@trentoequipment](https://www.instagram.com/trentoequipment)

